

Adjusting the door

Guide



Last update | Feb. 2019

Adjusting the door



It's mandatory to have **2 operators or more** for the assembling



1. Adjusting the door


⚠ Please follow the instructions carefully to avoid mistakes.

First of all, prepare a thickness of about 9 cm. A stack of books is a good option.

Open the door 90 degrees and place the thick one next to the sheet. With the help of another person (the door is very heavy), lift it about 3 millimeters without getting out of the hinge. Turn the door a little so that when you release it rest on the thick we had prepared.



Adjusting the door



Adjust the thickness so that the distance between the male and female hinge is effectively about 3 mm.

If you consider that the misalignment of the door is greater, you can increase this distance, but we recommend making small adjustments until a perfect fit is achieved.

At this point we have a gap between the two parts of the hinge as we can see in the image on the left. That allows us to raise the adjustable support of the hinge that is screwed with 2 screws to the frame.


⚠ It's very important to start with the two central supports of the four that have the door.

Adjusting the door



Once the screws are loosened, raise the support until the two parts of the hinge touch and retighten the support to the frame.

Repeat the operation with the second central hinge. Now you can remove the thickness that holds the door and try the adjustment. If the adjustment is correct, you can repeat the operation with the other two hinge supports. If not, you must put the grunt again and re-adjust.



Last update | Feb. 2019

